

Machine type : LARON Version 2

Date : 09.05.2008

Serial no. :

Technical Data :

Voltage	VAC	230	400
Frequency	Hz	50/60	50/60
Power consumption heating up controlled operation	W	4600	5700
	W	1750	2200
Drive	m/min	0,5 – 7 stepless	0,5 – 7 stepless
Welding temperature	°C	30 – 620 stepless	30 – 620 stepless
Air flow	%	60 – 100	60 – 100
Size LxWxH	mm	610 x 410 x 320	610 x 410 x 320
Weight	kg	35	35

We retain all copyrights of all descriptions, drawings and schedules contained in these operating instructions which may not be reproduced nor be made accessible by third parties or by competitors, neither in whole nor in part, unless we have expressly consented thereto.

Before start-up these operating instructions must be examined carefully because we will not assume any liability for any failures resulting from improper use. No warranty claims will be accepted if the automatic welding machine has been modified unless this has been done in consultation with the manufacturer / supplier.

The tool can be used for the applications mentioned in the present operating instructions only !

These operating instructions should always be accessible by the operator.

For after-sales service and orders please contact:

BAK Thermoplastic Welding Technology AG
Birkenweg 3
CH-6056 Kägiswil/Switzerland

Telefon: (0041) 041 6612250
Telefax: (0041) 041 6612251

Safety:

Pursuant to sec. 55 of VDE 0 100 (Regulations of the Association of German Electrotechnical Engineers), the automatic welding machine must be operated using a protective switch or an isolation transformer.

Protect the tool from wet and humidity!!!!

Operating the automatic welding machine is subject to applicable national regulations.

Observe applicable regulations for the prevention of accidents as well as technical rules for safe and professional operation.

Directive 92/ 57/ EWG dated June 24, 1992, shall be applicable by analogy.

Utilisation:

The Laron is an automatic welding machine for overlap welding to weld geomembranes (geomembranes width 20mm or 40mm). The machine must only be used to weld geomembranes (PE, PVC, TPO, ECB, EPDM, CSPE and bitumen) at the edge and uneven surfaces.

Automatic welding machines are manufactured according to the latest technology and in compliance with safety requirements.

Any improper use may result in dangers for the operator or third parties or may adversely affect machines and assets.

Only use the automatic welding machine if in technically perfect condition and for the purposes for which they are intended while observing the operating instructions.

For the neglect or for damages resulting from it the manufacturer / supplier will not accept any liability .

Any utilisation of the automatic welding machine, for other purposes than those for which it is intended, is subject to the consent of the manufacturer / supplier.

Work on electrical parts of welding machine may only be performed by an electrical engineer in compliance with electro-technical rules.

Indication of special risks:

All automatic welding machines may only be held and operated using the handles provided for this purpose.

A risk of burning exists on all uncovered metal parts. Avoid contact with these parts as they may achieve temperatures of up to 650°C.

Attention: Heat can reach combustible materials which are hidden.

Safety area:

The hot air stream of the automatic welding machine may not be directed to temperature-sensitive objects or living things. Ensure that a safety distance of 2 m is observed in all directions. Do not point the hot air stream onto the same position for a long time.

Security:

Before connecting the tool to the mains, check the rated voltage. The mains voltage must correspond to the rated voltage shown on the tool plate. Pursuant to sec. 55 of VDE 0 100 the automatic welding machine must be operated using a protective switch or an isolation transformer. Do not use the automatic welding machine if the connecting line or the plug is damaged, repairs have to be done by the manufacturer or authorised service personnel.

Extension cords:

When using extension cords the minimum diameter of cables must be observed. Extension cords must be approved and marked for their place of utilisation.

Stop operating the automatic welding machine if:

- connecting line or plug have been damaged
- safety installations have been damaged
- changes occur in the operating state

To separate the automatic welding machine from the electric system, change the main switch to “OFF” und unplug the mains plug.

Never spray water on automatic welding machine

(risk of short circuit)

Never use the automatic welding machine in hazardous or inflammable areas.

Do not leave the tool unobserved !!!

Attention: Let the automatic welding machine cool down before packing.


Before operating the machine examine the tool adjustment.

Basic adjustement:

Proceed with adjustments only in cold condition (burn danger!).

Nozzle adjustment:

- Changes of the nozzle adjustments can be done if screws are loosen
- For recommended settings use the following sketch




Guide roller adjustment:

- Bring the automatic welding machine into the welding position.
- Push the transport roller to the right in welding position
take care that the spring sheet engages.
- push the guide roller downward and fix it with the hexagon nut on the threaded bar.

Outside edge of the overlap, outside edge of pressure roll and outside edge of guide roller must form a line.

(see following sketch).



Start up of the automatic welding machine

Observe the section concerning safety of these operating instructions.

Before connecting the tool to the mains supply please check that:


- The main switch is on Pos. 0 OFF
- Drive switch is on Pos. 0
- Heating switch is on Pos. 0
- Potentiometer of the air flow is on Pos. 0 (100%)
- The hot air blower is on Pos. stand by (lifted up)
- Put the plug is into the socket and put the main switch on pos. 01

Switch the heating switch on.

The tool now heats up to the last selected set temperature.

To change the set temperature check the section of the controller adjustment.

Controller adjustment:




Select on the potentiometer the desired welding speed.


On switching position ON the drive starts immediately and is constantly running.



On switching position AUTO the drive starts only after sliding the nozzle
into the welding seam and stops immediately after taking out the nozzle.


Operating instructions
Automatic welding machine Laron

BAK
www.bak-ag.com 










Laron

Art. No.	Description	Art. No.	Description
6600047	Eron 230V Laron	6601100	Main switch (DV088)
6600048	Eron 400V Laron	6601149	LCD Display (DV089)
D-1079	O-ring 19x3.5 DIN3771	6601150	Steering bar base plate (DV096)
6601111	Pressure spring (DV001)	6601151	Steering bar lower part (DV097)
6601112	Sprocket wheel Z13 (DV012)	6601152	Grip of steering bar (Dv098)
6601113	Sprocket wheel Z14 (DV013)	DV100	Wing nut
6601114	Single roller chain (DV014)	6601153	Distance bushing (DV101)
6601118	Weight 1 (DV021)	6601155	Adjustable clamping lever (DV103)
6601119	Weight 2 (DV022)	6601156	Joint clamping link (DV104)
6601120	Chain tension adjuster (DV023)	6601157	Button scale (DV105)
6601121	Guide roller (DV029)	6601159	Power supply cord 230V (DV111)
6601122	Stop bolt with counter nut (DV031)	6601160	Power supply cord 400V (DV112)
6601123	T-handle (DV033)	6601161	Sprocket wheel clamp (DV114)
6601125	Circlip RA9 (DV036)	DV123	Countersunk screw, M6x16 DIN7991
6601126	Drag roller (DV037)	6601162	Cheese head screw, M6x20 (DV124)
6601127	Rocker drag roller (DV040)	6601164	Cheese head screw, M10x20 (DV128)
6601128	Drive pressure roller (DV042)	6601165	Cheese head screw, M12x35 (DV129)
6601129	Round belt roller (Dv045)	6601166	Cheese head screw, M12x70 (DV130)
6601133	Fixation block (DV052)	6601168	Countersunk screw M4x10 (DV136)
6601135	Bearing (DV056)	6601169	Disk A5,3 (DV137)
6601136	Shaft (DV057)	6601170	Disk A5,3 (DV138)
6601138	Gear sheet (DV059)	6601172	Support turbine housing Eron (DV141)
6601139	Guide handle block (DV062)	6601173	Disk B8,4 DIN9021 (DV142)
6601140	Guide rod (DV063)	6601174	Cheese head screw, M8x16, DIN 912 (DV143)
5107093	Rubber ring white (DV067)	6601175	Cheese head screw, M5x20 (DV146)
6601142	Silicon ring (DV068)	DV156	Disk B 6.4 DIN 9021
6601143	Round belt (DV069)	DV157	Hexagon bolt M8x50, DIN 933
6601103	Controller Laron (DV070)	DV158	Housing Laron
6601144	Locking ring Eron(lower part) (DV076)	DV159	Front plate Laron
6601145	Locking ring Eron(upper part) (DV077)	DV160	Base plate
6601147	Chain lock (DV080)	DV167	Planetary gear motor
6601148	Knob (Dv084)	DV175	Transport roller V2A
DV085	Cam switch, 1-pole	DV178	Cover transport roller
6601102	Cam switch, had-off-auto (DV086)	DV183	Ground piece

ERON 230V/400V, Art.-No.: 6600047/6600048




Spare parts list Eron 230V/400V, Art.-No.: 6600047/6600048

Art. No.	Description	Qty.
5101270	Gasket 70x48x4	1
5101274	Mica tube 47.6x134	1
5107612	Heating element Laron 230V	1
5108222	Overlap welding nozzle 40mm	1
5112693	Thermocouple	1
6100284	Countersunk screw M4x12 TX	3
6100287	Hexagon nut M5	1
6107591	Turbine	1
6107592	Turbine	1
6113695	Clixon 135°C	1
6600601	Air filter	1
6600606	Motor 230V SL	1
6600607	Carbon	2
6600612	Rubber ring	1
6600613	Turbine housing lower	1
6600614	Stripper	1
6600616	Countersunk screw M3x10 TX	6
6600622	Fillister head screw M4x10 TX	6
6600639	Handle	1
6600644	Terminal support	1
6600645	Turbine housing upper, with hole $\frac{1}{4}$ "	1
6600646	Elbow	1
6600647	cable sleeve 290mm	1
6600648	Hose coupling straight	1
6600653	Electronic circuit board 230V/400V	1
D-2224	Plastic hexagon nut PG16	2


Operating instructions
Automatic welding machine Laron

BAK
www.bak-ag.com



Operating instructions
Automatic welding machine Laron

BAK
www.bak-ag.com 



Operating instructions
Automatic welding machine Laron

BAK
www.bak-ag.com

